



# **SMCIPMITool**

## **User Guide**

Release 1.0a

Document SMCIPMITool\_Guide\_1.0a

Super Micro IPMITool User Guide

Release: 1.0a

Document: SMICIPMITool\_Guide\_1.0a

Document status: Standard

Document release date: 1/28/2011

Copyright © 2011 Super Micro

All Rights Reserved.

This document is protected by copyright laws and international treaties. All information, copyrights and any other intellectual property rights contained in this document are the property of Super Micro. Except as expressly authorized in writing by Super Micro, the holder is granted no rights to use the information contained herein and this document shall not be published, copied, produced or reproduced, modified, translated, compiled, distributed, displayed or transmitted, in whole or part, in any form or media.

# Contents

- 1 Introduction ..... 10
  - 1.1 Purpose ..... 10
  - 1.2 Set Up ..... 10
  - 1.3 Key Conventions ..... 11
    - 1.3.1 Keyboard Shortcuts ..... 11
  - 1.4 Third Party Software ..... 11
    - 1.4.1 JLine ..... 11
- 2 Usage and Command ..... 11
  - 2.2 Document Conventions ..... 12
- 3 Commands ..... 12
  - 3.1 system ..... 12
  - 3.2 failure ..... 14
  - 3.3 blade ..... 14
    - 3.3.1 blade status ..... 14
    - 3.3.2 blade index(es) ..... 15
      - 3.3.2.1 status ..... 15
      - 3.3.2.2 power ..... 16
      - 3.3.2.3 kvm ..... 16
      - 3.3.2.4 uid ..... 16
      - 3.3.2.5 sensor ..... 16
      - 3.3.2.6 bmc ..... 17
        - 3.3.2.6.1 ip ..... 17
        - 3.3.2.6.2 dhcp ..... 17
        - 3.3.2.6.3 vlan ..... 17
        - 3.3.2.6.4 ipmb ..... 17
      - 3.3.2.7 config ..... 17
  - 3.4 gigabit ..... 18
    - 3.4.1 gigabit status ..... 18
    - 3.4.2 gigabit index(es) ..... 18
      - 3.4.2.1 status ..... 18
      - 3.4.2.2 power ..... 19

3.4.2.3 wss.....	19
3.4.2.3.1 ip.....	19
3.4.2.3.2 netmask.....	19
3.4.2.3.3 gateway.....	19
3.4.2.3.4 datetime.....	19
3.4.2.3.5 username.....	19
3.4.2.3.6 password.....	19
3.4.2.4 ipmode.....	20
3.4.2.5 boot.....	20
3.4.2.6 restart.....	20
3.4.2.7 fd.....	20
3.5 power.....	20
3.5.1 power status.....	20
3.5.2 power index(es).....	21
3.5.2.1 status.....	21
3.5.2.2 power.....	21
3.5.2.3 fan.....	21
3.6 ib.....	21
3.6.1 ib status.....	21
3.6.2 ib index(es).....	22
3.6.2.1 status.....	22
3.6.2.2 power.....	22
3.7 cmm.....	22
3.7.1 cmm status.....	22
3.7.2 cmm index.....	23
3.7.2.1 status.....	23
3.7.2.2 dtime.....	23
3.7.2.3 ntp.....	23
3.7.2.4 reset.....	23
3.7.2.5 flash.....	23
3.7.2.6 ver.....	24
3.7.2.7 ip.....	24

3.7.2.8 mac .....	24
3.7.2.9 gateway .....	24
3.7.2.10 netmask .....	24
3.7.2.11 syncfg .....	24
3.7.2.12 opmode .....	24
3.7.2.13 dhcp .....	25
3.8 listtemp .....	25
3.9 sel .....	27
3.9.1 info .....	27
3.9.2 list .....	27
3.9.3 csv .....	27
3.9.4 clear .....	27
3.10 allsel .....	28
3.11 user .....	28
3.11.1 add .....	28
3.11.2 list .....	28
3.11.3 delete .....	28
3.11.4 level .....	28
3.11.5 test .....	29
3.12 vm .....	29
3.12.1 status .....	29
3.12.2 stop .....	29
3.12.3 floppy .....	30
3.12.4 iso .....	30
3.13 ipmi .....	30
3.13.1 sensor .....	30
3.13.2 power .....	31
3.13.2.1 up .....	32
3.13.2.2 down .....	32
3.13.2.3 softshutdown .....	32
3.13.2.4 reset .....	32
3.13.2.5 cycle .....	32

3.13.2.6 diag .....	32
3.13.3 acpi .....	32
3.13.4 lan.....	32
3.13.4.1 ip.....	32
3.13.4.2 mac .....	33
3.13.4.3 gateway.....	33
3.13.4.4 netmask .....	33
3.13.4.5 snmp .....	33
3.13.4.6 snmpcomm .....	34
3.13.4.7 arp .....	34
3.13.4.8 dhcp .....	34
3.13.4.9 vlan .....	34
3.13.5 fru.....	34
3.13.6 oem .....	35
3.13.6.1 clrint.....	35
3.13.6.2 id.....	35
3.13.6.3 uid.....	35
3.13.6.4 backup .....	35
3.13.6.5 restore .....	35
3.13.6.6 lani .....	36
3.13.7 reset .....	36
3.13.8 ver .....	36
3.13.9 flash .....	36
3.13.10 flashw .....	36
3.13.11 raw.....	36
3.13.12 ipmb .....	37
3.13.13 ipmboem.....	37
3.13.14 delcdr.....	37
3.14 shell .....	37
3.15 ver .....	38
3.16 ch .....	38
3.17 list.....	38

3.18 find .....	38
3.19 found .....	38
3.20 exec .....	38
3.21 host .....	39
3.21.1 list .....	39
3.21.2 reload .....	39
3.21.3 add .....	40
3.21.4 remove .....	40
3.21.5 rename .....	40
3.21.6 group .....	40
3.21.6.1 add .....	40
3.21.6.2 remove .....	40
3.21.6.3 rename .....	40
3.21.6.4 addhost .....	40
3.21.6.5 removehost .....	40
3.22 hostrun .....	41
3.23 sc .....	41
3.24 pminfo .....	41
3.25 nm .....	43
3.25.1 detect .....	43
3.25.2 ver .....	43
3.25.3 cap .....	43
3.25.4 status .....	44
3.25.5 stat .....	44
3.25.6 resetStat .....	44
3.25.7 pstate .....	44
3.25.8 tstate .....	45
3.25.9 ptstate .....	45
3.25.10 alert .....	45
3.25.11 scanPolicy .....	46
3.25.12 addPolicy .....	47
3.25.13 delPolicy .....	47

3.25.14	getPolicy .....	47
3.25.15	enablePolicy .....	47
3.25.16	disablePolicy .....	48
3.26	deploy.....	48
3.26.1	one .....	48
3.26.2	all.....	48
3.26.3	check .....	48
3.26.4	status .....	48
3.26.5	clear.....	48
3.27	kvmwa .....	48
3.28	ukvm.....	49
3.29	vmwa.....	49
3.29.1	dev1list .....	49
3.29.2	dev1drv.....	49
3.29.3	dev1stop .....	49
3.29.4	dev2list .....	49
3.29.5	dev2cd .....	50
3.29.6	dev2iso .....	50
3.29.7	dev2stop .....	50
3.29.8	allstatus .....	50
3.29.9	status .....	50
3.29.10	log.....	50
3.30	dcmi.....	50
3.30.1	find .....	50
3.30.2	cap .....	51
3.31	dr.....	52
3.31.1	list.....	53
3.31.2	iso .....	53
3.31.3	drv .....	53
3.32	kvm.....	54
3.33	kvmw.....	54
3.34	vmw.....	54

3.34.1 vmw floppy .....	54
3.34.2 vmw usbkey .....	54
3.34.3 vmw iso.....	54
3.34.4 vmw cd .....	54
3.34.5 vmw stopFloppy.....	54
3.34.6 vmw stopUsbkey.....	55
3.34.7 vmw stopISO .....	55
3.34.8 vmw stopCD.....	55
3.34.9 vmw status.....	55
3.35 sol.....	55
3.35.1 sol activate .....	55
3.35.2 sol deactivate .....	55
3.35.3 sol window.....	56
3.35.4 sol key.....	56
3.35.5 bitrate .....	56
Appendix A Command Categories.....	57
Appendix B VM Command Examples .....	59
B.1 AMI IPMI Firmware.....	59
B.2 ATEN IPMI Firmware.....	60
B.3 Peppercon IPMI Firmware .....	63
Appendix C Trap Receiver.....	66

# 1 Introduction

## 1.1 Purpose

IPMI (Intelligent Platform Management Interface) is an Intel-defined standard to allow a user to interface with a computer system to monitor the health of and manage the system.

The SMCIPMITool is a Supermicro utility that allows a user to interface with SuperBlade systems and IPMI devices via a CLI (Command Line Interface).

## 1.2 Set Up

This utility requires Sun JRE 1.5.x or above. Please install Java on your platform in advance of initiating SMCIPMITool. To download, please go to the following link:

<http://java.sun.com/javase/downloads/index.jsp>

There are two executable files in the SMCIPMITool utility:

- SMCIPMITool.jar: A jar file only.
- SMCIPMITool.exe : A windows executable wrapper for SMCIPMITool.jar

Users can choose either the jar or a native executable file. For Linux environments, an extra setting to the environment is required, as shown below.

Add jre to your PATH line in the .bashrc file: `PATH=/usr/java/jre1.5.0_12/bin:$PATH`

The "jre1.5.0\_12" folder may change depending on your version of Java.

## 1.3 Key Conventions

### 1.3.1 Keyboard Shortcuts

Keys	Action
Up Arrow /Down Arrow	Displays the previously executed command
Ctrl + A	Moves the cursor to the previous command line
Ctrl + C	Exits from the SMCIPMITool prompt
Backspace/ Ctrl + H	Removes a single character
TAB	Completes a command without typing the full word
Left Arrow /Right Arrow	Traverses the current line

## 1.4 Third Party Software

### 1.4.1 JLine

SMCIPMITool uses JLine for command history and tab-completion. JLine is a Java library used to handle console input and is similar in functionality to BSD editline and GNU readline. People familiar with the readline/editline capabilities for modern shells (such as bash and tcsh) will find most of the command editing features of JLine to be familiar.

Please refer to <http://jline.sourceforge.net/index.html> for more information.

## 2 Usage and Command

Enter the console mode and run the following command to start (online help is included):

Usage:

```
java -jar SMCIPMITool.jar <IP> <username> <password> [commands ... ]
```

or

```
SMCIPMITool <IP> <username> <password> [commands ... ]
```

## 2.2 Document Conventions

- The syntax of the CLI command is given in **Courier New 11 bold**.
- Elements in (< >) indicate the field required as input along with a CLI command, for example **< integer (100-1000)>**.
- Elements in square brackets ([ ]) indicate optional fields for a command.
- Both “ \* “ and “ , , ” may be used to specify the numbers for the blade/gigabit/power/ib index(es) commands. For example:

```
CMM> blade 1,2,3 status
```

```
CMM> gigabit * status
```

## 3 Commands

This section lists the commands available with SMCIPMITool. You must follow the usage protocol as described in the previous section.

### 3.1 system

The system command displays the system information. In a blade system, this command will also list the modules present (CMM modules, Gb switches, power supplies, etc.).

Usage: **system**

Example Output:

```
Blade Module (20/20)
```

```
-----
```

Blade	Power	KVM	UID	Error	BMC	Watt	MB
-----	-----	---	---	-----	---	-----	--
Blade 1	Off	Selected			Yes	350W	B8DTT
Blade 2	Off				Yes	400W	B8DTT
Blade 3	On				Yes	350W	B8DTT
Blade 4	On				Yes	350W	B8DTT
Blade 5	On				Yes	350W	B8DTT
Blade 6	On				Yes	350W	B8DTT
Blade 7	On				Yes	350W	B8DTT

Blade 8	On				Yes	350W	B8DTT
Blade 9	On				Yes	350W	B8DTT
Blade 10	On				Yes	350W	B8DTT
Blade 11	Off				Yes	400W	B8DTT
Blade 12	Off				Yes	400W	B8DTT
Blade 13	On				Yes	350W	B8DTT
Blade 14	On				Yes	350W	B8DTT
Blade 15	On				Yes	350W	B8DTT
Blade 16	On				Yes	350W	B8DTT
Blade 17	On				Yes	350W	B8DTT
Blade 18	On				Yes	350W	B8DTT
Blade 19	On				Yes	350W	B8DTT
Blade 20	On				Yes	350W	B8DTT

Gigabit Switch Module (1/2)

```

-----
GBSW | Power | Error | Init | Switch | 2.5V | 1.25V | Type
---- | ----- | ----- | ---- | - | ---- | - | -----
GBSW 1 | On | | Not | 61C/142F | 2.48V | 1.192V | L3 Switch

```

Power Supply Module (4/4)

```

-----
PS | Power | Fan 1 | Fan 2 | Temp. | Watts | DC | AC | F/W | FRU
-- | ----- | ----- | ----- | ----- | ----- | -- | -- | --- | ---
PS 1 | On | 5152 | 5152 | 56C/133F | 2000 | N/A | N/A | 2.6 | 01
PS 2 | On | 5381 | 5381 | 54C/129F | 2000 | N/A | N/A | 2.6 | 01
PS 3 | On | 5267 | 5152 | 57C/135F | 2000 | N/A | N/A | 2.6 | 01
PS 4 | On | 7328 | 7099 | 54C/129F | 2000 | N/A | N/A | 2.6 | 01

```

IBQDR Module (1/2)

```

-----
IBQDR   | Power | Temp. Switch | Temp. Board | 3.3V | 1.25V
----- | ----- | ----- | ----- | ---- | -----
IBQDR 1 | On    | 57C/135F    | 56C/133F    | 3.24V | 1.18V

```

CMM Module(1/2)

```

-----
CMM     | M/S   | Status
----   | ---   | -----
CMM 1  | Master | OK

```

CMM 1 is being managed now

## 3.2 failure

The failure command brings up a failure report, which lists all failure messages from the system.

Usage: **failure**

## 3.3 blade

The blade command will bring up the following subcommands.

### 3.3.1 blade status

This command will display the status of all the blade units in the system.

Usage: **blade status**

Example Output:

```

Blade Module (20/20)
-----
Blade    | Power | KVM      | UID | Error | BMC | Watt | MB
----- | ----- | ---      | --- | ----- | --- | ---- | --
Blade 1  | Off   | Selected |     |         | Yes | 350W | B8DTT
Blade 2  | Off   |          |     |         | Yes | 400W | B8DTT

```

Blade 3	On				Yes	350W	B8DTT
Blade 4	On				Yes	350W	B8DTT
Blade 5	On				Yes	350W	B8DTT
Blade 6	On				Yes	350W	B8DTT
Blade 7	On				Yes	350W	B8DTT
Blade 8	On				Yes	350W	B8DTT
Blade 9	On				Yes	350W	B8DTT
Blade 10	On				Yes	350W	B8DTT
Blade 11	Off				Yes	400W	B8DTT
Blade 12	Off				Yes	400W	B8DTT
Blade 13	On				Yes	350W	B8DTT
Blade 14	On				Yes	350W	B8DTT
Blade 15	On				Yes	350W	B8DTT
Blade 16	On				Yes	350W	B8DTT
Blade 17	On				Yes	350W	B8DTT
Blade 18	On				Yes	350W	B8DTT
Blade 19	On				Yes	350W	B8DTT
Blade 20	On				Yes	350W	B8DTT

### 3.3.2 blade index(es)

This command is used to check the individual blades in the system. The following subcommands may be used for a specific blade.

#### 3.3.2.1 status

Used to check the status of the individual blade specified.

Usage: **blade <blade number> status**

Example Output:

[ 1 ]:

Blade	Power	KVM	UID	Error	BMC	Watt	MB
-----	-----	---	---	-----	---	----	--
Blade 1	Off	Selected			Yes	350W	B8DTT

[ 2 ]:

```

Blade      | Power | KVM      | UID | Error | BMC | Watt | MB
-----    | ----- | ---      | --- | ----- | --- | ---- | --
Blade 2    | Off   |          |     |         | Yes | 400W | B8DTT

```

### 3.3.2.2 power

Used to access power control for the individual blade specified.

Usage: **blade <blade number> power [up|down|softshutdown|reset]**

Example Output:

```

[ 1]:
Power: Off

Available commands: up, down, softshutdown, reset

[ 2]:
Power: Off

Available commands: up, down, softshutdown, reset

```

### 3.3.2.3 kvm

Requests a kvm switch for the individual blade specified.

Usage: **blade <blade number> kvm**

### 3.3.2.4 uid

Used to turn a UID LED on or off as specified on an individual blade.

Usage: **blade <blade number> uid <on/off>**

### 3.3.2.5 sensor

Used to get sensor readings from the individual blade specified.

Usage: **blade <blade number> sensor**

Example Output:

```

Status | Sensor                | Reading | Low Limit | High Limit |
-----|-----                |-----|-----|-----|
OK     | CPU1 Temp             | 1C/ 34F | N/A      | 80C/176F |
OK     | CPU2 Temp             | 1C/ 34F | N/A      | 80C/176F |
OK     | System Temp           | 64C/147F | N/A      | 80C/176F |
OK     | CPU1 Vcore            | 0.95 V  | 0.6 V    | 1.38 V   |

```

OK	CPU2 Vcore		0.96 V		0.6 V		1.38 V	
OK	CPU1 DIMM		1.53 V		1.2 V		1.65 V	
OK	CPU2 DIMM		1.53 V		1.2 V		1.65 V	
OK	1.5V		1.52 V		1.34 V		1.65 V	
OK	3.3V		3.16 V		2.96 V		3.63 V	
OK	3.3VSB		3.36 V		2.96 V		3.63 V	
OK	5V		5.06 V		4.49 V		5.5 V	
OK	12V		12.19 V		10.75 V		13.25 V	
OK	VBAT		3.36 V		2.96 V		3.63 V	

### 3.3.2.6 bmc

This command will bring up the following subcommands related to the BMC of an individual blade.

#### 3.3.2.6.1 ip

Used to get or set the IP address of a blade's BMC.

Usage (to get): `blade <blade number> bmc ip`

Usage (to set): `blade <blade number> bmc ip <IP>`

#### 3.3.2.6.2 dhcp

Used to enable or disable the DHCP (Dynamic Host Configuration Protocol) of a blade.

Usage: `blade <blade number> bmc dhcp [enable|disable]`

#### 3.3.2.6.3 vlan

Used to display or enable or disable an individual blade's VLAN (Virtual LAN).

Usage: `blade <blade number> bmc vlan [<enable|disable> >tag>]`

#### 3.3.2.6.4 ipmb

Used to send a raw IPMI command to an individual blade.

Usage: `blade <blade number> bmc ipmb <netFn> <cmd> [data]`

### 3.3.2.7 config

Used to get the configuration of the individual blade specified.

Usage: `blade <blade number> config`

Example Output:

MB ID = BD

```

Pwr Consumption = 350W
CPUs            = 2
CPU Type       = undefined
CPU Speed      = 2.90Ghz
DIMMs          = 2
Memory Size    = 8192MB
Memory Speed   = 1066Mhz
LANs           = 2
LAN 1 MAC     = 00:30:48:F7:65:CC
LAN 2 MAC     = 00:30:48:F7:65:CD
MB SN         = ??????????????????

```

## 3.4 gigabit

Entering the gigabit command will bring up the following subcommands.

### 3.4.1 gigabit status

This command will display the status of all the Gb switch units in the system.

Usage: **gigabit status**

Example Output:

```

Gigabit Switch Module (1/2)
-----
GBSW  | Power | Error | Init | Switch | 2.5V | 1.25V | Type
----  | ----- | ----- | ---- | ----- | ---- | ----- | -----
GBSW 1 | On    |      | Not  | 61C/142F | 2.496V | 1.192V | L3 Switch

```

### 3.4.2 gigabit index(es)

This command brings up the following commands related to an individual Gb switch in the system as specified.

#### 3.4.2.1 status

Used to display the status of the gigabit switch specified.

Usage: **gigabit <gigabit number> status**

Example Output:

```
GBSW   | Power | Error | Init |   Switch |   2.5V |   1.25V | Type
-----|-----|-----|-----|-----|-----|-----|-----
GBSW 1 | On    |       | Not  | 61C/142F | 2.48V | 1.192V | L3 Switch
```

### **3.4.2.2 power**

Used to access power control for the gigabit switch specified.

Usage: `gigabit <gigabit number> power <on|off|reset>`

### **3.4.2.3 wss**

Used to access WSS (WebSuperSmart) web configuration control for the gigabit switch specified.

#### **3.4.2.3.1 ip**

Used to get or set the IP address of a gigabit switch.

Usage: `gigabit <gigabit number> wss ip [IP]`

#### **3.4.2.3.2 netmask**

Used to get or set the netmask address of a gigabit switch.

Usage: `gigabit <gigabit number> wss netmask [netmask]`

#### **3.4.2.3.3 gateway**

Used to get or set the gateway address of a gigabit switch.

Usage: `gigabit <gigabit number> wss gateway [gateway]`

#### **3.4.2.3.4 datetime**

Used to get or set the date and time settings for a gigabit switch.

Usage: `gigabit <gigabit number> wss datetime [datetime]`

Example Output:

```
12/29/2010 02:56:02
```

#### **3.4.2.3.5 username**

Used to get or set the username of WSS web for a gigabit switch.

Usage: `gigabit <gigabit number> wss username [username]`

#### **3.4.2.3.6 password**

Used to get or set the password of WSS web for a gigabit switch.

Usage: `gigabit <gigabit number> wss password [password]`

### 3.4.2.4 ipmode

Used to get or set the IP mode of the gigabit switch specified.

Usage (to get): `gigabit <gigabit number> ipmode`

Usage (to set): `gigabit <gigabit number> ipmode <mode>`

### 3.4.2.5 boot

Used to get or set the boot image of the gigabit switch specified.

Usage: `gigabit <gigabit number> boot [image number]`

### 3.4.2.6 restart

Used to soft restart the gigabit switch specified.

Usage: `gigabit <gigabit number> restart`

### 3.4.2.7 fd

Used to reset to factory default for the gigabit switch specified.

Usage: `gigabit <gigabit number> fd`

## 3.5 power

Entering the power command will bring up the following subcommands.

### 3.5.1 power status

This command will display the status of all the power supply units in the blade system.

Usage: `power status`

Example Output:

Power Supply Module (4/4)

-----

PS	Power	Fan 1	Fan 2	Temp.	Watts	DC	AC	F/W	FRU
--	-----	-----	-----	-----	-----	--	--	---	---
PS 1	On	5152	5152	57C/135F	2000	N/A	N/A	2.6	01
PS 2	On	5381	5381	54C/129F	2000	N/A	N/A	2.6	01
PS 3	On	5152	5152	58C/136F	2000	N/A	N/A	2.6	01
PS 4	On	7328	7213	54C/129F	2000	N/A	N/A	2.6	01

## 3.5.2 power index(es)

This command is used to check the individual power supplies in the blade system and brings up the following commands:

### 3.5.2.1 status

Used to display the status of the power supply specified.

Usage: **power <power number> status**

Example Output:

```
PS   | Power | Fan 1 | Fan 2 | Temp.   | Watts | DC | AC | F/W | FRU
--   | -----| -----| -----| -----| -----| -- | -- | --- | ---
PS 1 | On    | 5152  | 5152  | 56C/133F | 2000  | N/A | N/A | 2.6 | 01
```

### 3.5.2.2 power

Used to access power control for the power supply specified.

Usage: **power <power number> <on|off>**

### 3.5.2.3 fan

Used to access fan control for the power supply specified.

Usage: **power <power number> fan <1|2|3|4|auto>**

## 3.6 ib

Entering the ib command will bring up the following subcommands.

### 3.6.1 ib status

This command will display the status of all the InfiniBand switches in the system.

Usage: **ib status**

Example Output:

```
IBQDR Module (1/2)
-----
IBQDR   | Power | Temp. Switch | Temp. Board | 3.3V | 1.25V
-----|-----|-----|-----|-----|-----
IBQDR 1 | On    | 57C/135F    | 56C/133F    | 3.24V | 1.18V
```

## 3.6.2 ib index(es)

This command is used to check the individual InfiniBand switches in the system and will bring up the following subcommands:

### 3.6.2.1 status

Used to display the status of the InfiniBand switch specified.

Usage: **ib <ib number> status**

Example Output:

```
IB   | Power | Init | VVDD | 3.3V Aux | 1.2V | 1.8V | 3.3V | Temp.
--   | -----| ----| ----| -| -| -| -| -----
IB 1 | Off   | OK   | 1.92V | 2.85V | 0.78V | 1.48V | 2.85V | 0C/32F
```

### 3.6.2.2 power

Used to access power control for the InfiniBand switch specified.

Usage: **ib <ib number> power <on|off|reset>**

## 3.7 cmm

Entering the cmm command will bring up the following subcommands.

### 3.7.1 cmm status

This command will display the status of all the CMM in the system.

Usage: **cmm status**

Example Output:

```
CMM Module(1/2)
-----
CMM   | M/S   | Status
---   | ---   | -----
CMM 1 | Master | OK

CMM 1 is being managed now

CMM IP address:
```

-----  
CMM 1 IP: 172.31.100.235

## 3.7.2 cmm index

This command is used to check the individual CMM in the system and will bring up the following subcommands:

### 3.7.2.1 status

Used to display the status of the CMM specified.

Usage: **cmm <cmm number> status**

Example Output:

```
CMM   | M/S   | Status
---   | ---   | -----
CMM 1 | Master | OK
```

CMM 1 is being managed now

### 3.7.2.2 dtime

Used to get or set CMM date and time.

Usage: **cmm <cmm number> dtime [datetime]**

Example Output:

```
12/29/2010 02:56:02
```

```
(Data time format for setting: "MM/dd/yyyy HH:mm:ss")
```

### 3.7.2.3 ntp

Used to synch the time with the NTP servers.

Usage: **cmm <cmm number> ntp <UTC offset> <NTP1> [NTP2]**

### 3.7.2.4 reset

Used to reset the CMM specified.

Usage: **cmm <cmm number> reset**

### 3.7.2.5 flash

Used to flash CMM firmware to the CMM specified with the filename of the flash upgrade noted..

Usage: `cmm <cmm number> flash <filename>`

### **3.7.2.6 ver**

Used to display the firmware version in the CMM specified.

Usage: `cmm ver`

Example Output:

```
Version:2.2.64 build 5420
```

### **3.7.2.7 ip**

Used to get or set the IP address of the CMM specified.

Usage: `cmm <cmm number> ip [IP address]`

IP address format: `###.###.###.###`

### **3.7.2.8 mac**

Used to get or set the MAC address of the CMM specified.

Usage: `cmm <cmm number> mac [mac address]`

MAC address format: `###.###.###.###`

### **3.7.2.9 gateway**

Used to get or set the Gateway address of the CMM specified.

Usage: `cmm <cmm number> gateway [gateway address]`

Gateway address format: `###.###.###.###`

### **3.7.2.10 netmask**

Used to get or set the Netmask IP address of the CMM specified.

Usage: `cmm <cmm number> netmask [netmask address]`

Netmask address format: `###.###.###.###`

### **3.7.2.11 syncfg**

Used to sync the configuration to the slave CMM specified.

### **3.7.2.12 opmode**

Used to get or set the operational mode for the CMM specified.

Usage: `cmm <cmm number> opmode [mode]`

Mode Choices: 0 = Enterprise 1 = Office

### 3.7.2.13 dhcp

Used to enable or disable the DHCP (Dynamic Host Configuration Protocol) of the CMM.

Usage: `cmm <cmm number> dhcp [enable|disable]`

## 3.8 listtemp

Entering the listtemp command will display the temperatures of all the modules in the blade system.

Usage: `listtemp`

Example Output:

Status	Module	Sensor	Reading	High Limit
OK	Blade 3	CPU1 Temp	Low	N/A
OK	Blade 3	CPU2 Temp	Low	N/A
OK	Blade 3	System Temp	56C/133F	80C/176F
OK	Blade 4	CPU1 Temp	Low	N/A
OK	Blade 4	CPU2 Temp	Low	N/A
OK	Blade 4	System Temp	57C/135F	80C/176F
OK	Blade 5	CPU1 Temp	Low	N/A
OK	Blade 5	CPU2 Temp	Low	N/A
OK	Blade 5	System Temp	63C/145F	80C/176F
OK	Blade 6	CPU1 Temp	Low	N/A
OK	Blade 6	CPU2 Temp	Low	N/A
OK	Blade 6	System Temp	64C/147F	80C/176F
OK	Blade 7	CPU1 Temp	Medium	N/A
OK	Blade 7	CPU2 Temp	Low	N/A
OK	Blade 7	System Temp	62C/144F	80C/176F
OK	Blade 8	CPU1 Temp	Low	N/A
OK	Blade 8	CPU2 Temp	Low	N/A
OK	Blade 8	System Temp	63C/145F	80C/176F
OK	Blade 9	CPU1 Temp	Medium	N/A

OK	Blade 9	CPU2 Temp		Low		N/A	
OK	Blade 9	System Temp		62C/144F		80C/176F	
	Blade 10	CPU1 Temp		N/A		N/A	
OK	Blade 10	CPU2 Temp		Low		N/A	
OK	Blade 10	System Temp		59C/138F		80C/176F	
OK	Blade 13	CPU1 Temp		Low		N/A	
OK	Blade 13	CPU2 Temp		Low		N/A	
OK	Blade 13	System Temp		60C/140F		80C/176F	
OK	Blade 14	CPU1 Temp		Low		N/A	
OK	Blade 14	CPU2 Temp		Low		N/A	
OK	Blade 14	System Temp		60C/140F		80C/176F	
OK	Blade 15	CPU1 Temp		Medium		N/A	
OK	Blade 15	CPU2 Temp		Low		N/A	
OK	Blade 15	System Temp		63C/145F		80C/176F	
OK	Blade 16	CPU1 Temp		Low		N/A	
OK	Blade 16	CPU2 Temp		Low		N/A	
OK	Blade 16	System Temp		61C/142F		80C/176F	
OK	Blade 17	CPU1 Temp		Low		N/A	
OK	Blade 17	CPU2 Temp		Low		N/A	
OK	Blade 17	System Temp		63C/145F		80C/176F	
OK	Blade 18	CPU1 Temp		Medium		N/A	
OK	Blade 18	CPU2 Temp		Medium		N/A	
OK	Blade 18	System Temp		65C/149F		80C/176F	
OK	Blade 19	CPU1 Temp		Low		N/A	
OK	Blade 19	CPU2 Temp		Medium		N/A	
OK	Blade 19	System Temp		62C/144F		80C/176F	
	Blade 20	CPU1 Temp		N/A		N/A	
OK	Blade 20	CPU2 Temp		Low		N/A	
OK	Blade 20	System Temp		62C/144F		80C/176F	
OK	Power 1	Temp.		56C/133F		85C/185F	

OK	Power 2	Temp.		54C/129F		85C/185F	
OK	Power 3	Temp.		57C/135F		85C/185F	
OK	Power 4	Temp.		54C/129F		85C/185F	
OK	GBSW 1	Switch		61C/142F		80C/176F	
OK	InfiniBand 1	Temp.		0C/ 32F		80C/176F	

## 3.9 sel

Entering the sel command will bring up the following subcommands for the system event log.

### 3.9.1 info

This command gives the information on the system event log.

Usage: **sel info**

Example Output:

```
Total Entries:          2
SEL Version:           1.5
Free Space:            9180bytes
Recent Entry Added:    12/20/2010 22:37:33
Recent Entry Erased:   Pre-Init 00:00:00
```

### 3.9.2 list

This command will display the list of entries to the system event log.

Usage: **sel list**

### 3.9.3 csv

This subcommand will save the system event log as a csv file with the name specified in the filename.

Usage: **sel csv <filename>**

### 3.9.4 clear

This command will clear the system event log.

Usage: **sel clear**

## 3.10 allsel

Entering the allsel command will save all blade system event logs as a csv file with the name specified in the filename.

Usage: **allsel** <filename>

## 3.11 user

Entering the user command will list the following user management subcommands.

### 3.11.1 add

Use this command to enter the name of a new user.

Usage: **user add** <user ID> <user name> <password> <privilege>

### 3.11.2 list

Entering the list command will display the users.

Usage: **user list**

Example Output:

```
Maximum number of Users          : 10
Count of currently enabled Users : 2
User ID | User Name      | Privilege Level | Enable
----- | -
2 | ADMIN         | Administrator   | Yes
```

### 3.11.3 delete

Entering the delete command allows you to delete a user.

Usage: **user delete** <user ID>

### 3.11.4 level

Entering the level command allows you to update the level of a user.

Usage: **user level** <user ID> <privilege>

The following levels may be assigned:

- 4: Administrator level

- 3: Operator level
- 2: User level
- 1: Callback

### 3.11.5 test

Entering the test command allows you to test logging in as a specific user.

Usage: **user test** <user ID> <password>

## 3.12 vm

Entering the vm command will list the following virtual media management subcommands. Refer to Appendix B for more on VM commands.

### 3.12.1 status

Using the status command lists the status of the drives present in the system.

Usage: **vm status**

Example Output:

```
Drive 1

Device Status = CD-ROM image on Windows share set

Image Size = 522766336 (bytes)

Access Mode = Read-Only

Image source = //192.168.10.43/iso/cd1.iso
```

```
Drive 2

Device Status = CD-ROM image on Windows share set

Image Size = 522766336 (byte)

Access Mode = Read-Only

Image source = //192.168.10.43/iso/cd2.iso
```

### 3.12.2 stop

Using the stop command allows you to stop the specified drive.

Usage: **vm stop** <drive ID>

### 3.12.3 floppy

Using the floppy command allows you to upload a floppy image as virtual media.

Usage: `vm floppy <drive ID> <floppy_filename>`

### 3.12.4 iso

Using the iso command allows you to share virtual media via Windows.

Usage: `vm iso <drive ID> <host IP> <share name> <path to image> [username] [password]`

Example:

```
CMM>vm iso 1 192.168.10.43 iso cd1.iso  
done
```

## 3.13 ipmi

Entering the ipmi command will list the following ipmi device management subcommands.

### 3.13.1 sensor

Using the sensor command will display the sensor status and data.

Usage: `ipmi sensor`

Example Output:

```
Getting SDR data ...
```

```
Getting sensors ...
```

Status	(#) Sensor	Reading	Low Limit	High Limit
OK	(7) CPU1 Temp	Low		
OK	(8) CPU2 Temp	Low		
OK	(9) System Temp	63C/145F	-5C/23F	75C/167F
OK	(10) CPU1 Vcore	0.92 V	0.82 V	1.35 V
OK	(11) CPU2 Vcore	0.88 V	0.82 V	1.35 V
OK	(12) +5V	5.12 V	4.48 V	5.53 V
OK	(13) +5VSB	5.12 V	4.48 V	5.53 V
OK	(14) +12V	12.19 V	10.7 V	13.25 V

OK	(15) -12V		-11.99 V		-12.58 V		-11.22 V	
OK	(16) +3.3V		3.26 V		2.92 V		3.64 V	
OK	(17) +3.3VSB		3.24 V		2.92 V		3.64 V	
OK	(18) VBAT		3.21 V		2.92 V		3.64 V	
OK	(19) Fan1		4320 RPM		675 RPM		34155 RPM	
	(20) Fan2		0 RPM		675 RPM		34155 RPM	
OK	(21) Fan3		4320 RPM		675 RPM		34155 RPM	
OK	(22) Fan4		4185 RPM		675 RPM		34155 RPM	
	(23) Fan5		0 RPM		675 RPM		34155 RPM	
	(24) Fan6		0 RPM		675 RPM		34155 RPM	
	(25) Fan7		0 RPM		675 RPM		34155 RPM	
	(26) Fan8		0 RPM		675 RPM		34155 RPM	
OK	(27) P1-DIMM1A Temp		47C/117F		-5C/23F		75C/167F	
	(28) P1-DIMM1B Temp		N/A		-5C/23F		75C/167F	
OK	(29) P1-DIMM2A Temp		48C/118F		-5C/23F		75C/167F	
	(30) P1-DIMM2B Temp		N/A		-5C/23F		75C/167F	
OK	(31) P1-DIMM3A Temp		46C/115F		-5C/23F		75C/167F	
	(32) P1-DIMM3B Temp		N/A		-5C/23F		75C/167F	
OK	(33) P2-DIMM1A Temp		38C/100F		-5C/23F		75C/167F	
	(34) P2-DIMM1B Temp		N/A		-5C/23F		75C/167F	
OK	(35) P2-DIMM2A Temp		37C/99F		-5C/23F		75C/167F	
	(36) P2-DIMM2B Temp		N/A		-5C/23F		75C/167F	
OK	(37) P2-DIMM3A Temp		37C/99F		-5C/23F		75C/167F	
	(38) P2-DIMM3B Temp		N/A		-5C/23F		75C/167F	
OK	(39) Intrusion		00 C0 00 00		N/A		N/A	
OK	(40) PS Status		00 C0 00 00		N/A		N/A	

### 3.13.2 power

Using the power command will list the following power control options.

### **3.13.2.1 up**

Use the power up command to power up a system.

Usage: `ipmi power up`

### **3.13.2.2 down**

Use the power down command to power down a system.

Usage: `ipmi power down`

### **3.13.2.3 softshutdown**

Use the softshutdown command to initiate a soft shutdown of a system.

Usage: `ipmi power softshutdown`

### **3.13.2.4 reset**

Use the reset command to initiate a reset of a system. Using the PXE option forces the first boot device to be used as PXE in the next boot only.

Usage: `ipmi power reset [PXE]`

### **3.13.2.5 cycle**

Use the cycle command to power cycle of a system.

Usage: `ipmi power cycle [interval]`

### **3.13.2.6 diag**

Use the diag command to initiate a diagnostic interrupt of a system.

Usage: `ipmi power diag`

## **3.13.3 acpi**

Using the acpi command will display the ACPI (Advanced Configuration and Power Interface) status.

Usage: `ipmi acpi`

## **3.13.4 lan**

Using the acpi command will list the following LAN (Local Area Network) management subcommands.

### **3.13.4.1 ip**

Use the ip command to get/set the specified ipmi address.

Usage: `ipmi lan ip [ip]`

Address format: ###.###.###.###

### 3.13.4.2 mac

Use the ip command to get/set the specified MAC address.

Usage: `ipmi lan mac [mac]`

Address format: ###.###.###.###

### 3.13.4.3 gateway

Use the gateway command to get/set the specified Gateway address.

Usage: `ipmi lan gateway [gateway IP]`

Address format: ###.###.###.###

### 3.13.4.4 netmask

Use the netmask command to get/set the specified Netmask.

Usage: `ipmi lan netmask [netmask]`

Address format: ###.###.###.###

### 3.13.4.5 snmp

Use the snmp command to get/set the specified SNMP destination.

Usage: `ipmi lan snmp [<seq> <ip> [mac]]`

Example Output:

Seq	IP	MAC
---	--	---
1	0.0.0.0	00:00:00:00:00:00
2	192.168.12.150	00:00:00:00:00:00
3	0.0.0.0	00:00:00:00:00:00
4	0.0.0.0	00:00:00:00:00:00
5	0.0.0.0	00:00:00:00:00:00
6	0.0.0.0	00:00:00:00:00:00
7	0.0.0.0	00:00:00:00:00:00
8	0.0.0.0	00:00:00:00:00:00
9	0.0.0.0	00:00:00:00:00:00

```
10          0.0.0.0    00:00:00:00:00:00
11          0.0.0.0    00:00:00:00:00:00
12          0.0.0.0    00:00:00:00:00:00
13          0.0.0.0    00:00:00:00:00:00
14          0.0.0.0    00:00:00:00:00:00
15          0.0.0.0    00:00:00:00:00:00
```

### 3.13.4.6 *snmpcomm*

Use the `snmpcomm` command to get/set the SNMP community string.

Usage: `ipmi lan snmpcomm [community string]`

Example Output:

```
public
```

### 3.13.4.7 *arp*

Use the `arp` command to enable BMC-generated gratuitous ARPs.

Usage: `ipmi lan arp [on|off]`

### 3.13.4.8 *dhcp*

Use the `dhcp` command to enable or disable DHCP (Dynamic Host Configuration Protocol).

Usage: `ipmi lan dhcp [enable|disable]`

### 3.13.4.9 *vlan*

Use the `vlan` command to enable or disable virtual LAN (vlan).

Usage: `ipmi lan vlan [<enable|disable> <tag>]`

## 3.13.5 *fru*

Using the `fru` command will list the information on the FRU (Field Replaceable Unit).

Usage: `ipmi fru`

Example Output:

```
Getting FRU ...

Chassis Type           = undefined (00h)
Chassis Part Number    =
Chassis Serial Number  =
```

Board Manufacturer Name = Super Micro  
Board Product Name = IPMI2.0  
Board Serial Number =  
Board Part Number = AOC-SIMCM-O-P  
Board FRU File ID =  
Product Manufacturer Name = Super Micro  
Product Name = IPMI2.0  
Product PartModel Number = SBM-CMM-001  
Product Version = 1.0  
Product Serial Number =  
Product Asset Tag =  
Product FRU File ID =

### 3.13.6 oem

Using the oem command will list the following subcommands.

#### 3.13.6.1 *clrint*

Use the clrint command to clear the chassis intrusion detection switch.

Usage: **ipmi oem clrint**

#### 3.13.6.2 *id*

Use the id command to display the motherboard ID (available for SIMxx IPMI only).

Usage: **ipmi oem id**

#### 3.13.6.3 *uid*

Use the uid command to turn the UID LED on or off (if supported by the device).

Usage: **ipmi oem uid [on|off]**

#### 3.13.6.4 *backup*

Use the backup command to backup the configuration file as the filename specified.

Usage: **ipmi oem backup <filename>**

#### 3.13.6.5 *restore*

Use the restore command to restore the configuration from the filename specified.

Usage: **ipmi oem restore <filename> <option>**

### 3.13.6.6 *lani*

Use the `lani` command to interface with the IPMI LAN.

Usage: `ipmi oem lani [0|1|2]`

### 3.13.7 `reset`

Using the `reset` command will reset IPMI.

Usage: `ipmi reset`

### 3.13.8 `ver`

Using the `ver` command will display the following information relating to the IPMI version in use.

Usage: `ipmi ver`

Example Output:

```
Firmware Revision = 02.02
IPMI Version      = 2.0
Manufacturer ID   = C5 28 00
product ID        = 04 00 00
OEM Version       = 2.2.64 build 5420
OEM Tag           = Dec-15-2010-17-15-CMM
```

### 3.13.9 `flash`

Use the `flash` command to flash a new version of SIM IPMI firmware as specified by the filename.

Usage: `ipmi flash <filename>`

### 3.13.10 `flashw`

Use the `flashw` command to flash a new version of SIMSOW IPMI firmware as specified by the filename.

Usage: `ipmi flashw <filename>`

### 3.13.11 `raw`

Use the `raw` command to send an IPMI raw command.

Usage: `ipmi raw <netFn> <cmd> [data]`

### 3.13.12 ipmb

Use the ipmb command to send an IPMI raw command.

Usage: `ipmi ipmb <ch> <addr> <netFn> <cmd> [data]`

### 3.13.13 ipmboem

Use the ipmboem command to send an IPMI raw command.

Usage: `ipmi ipmb <ch> <addr> <netFn> <cmd> [data]`

### 3.13.14 delcdr

Use the delcdr command to delete the SDR.

Usage: `ipmi delcdr <SDR record ID>`

## 3.14 shell

Entering the shell command will enter the shell mode.

Usage: shell

Example:

```
D:\>SMCIPMITool 192.168.0.1 ADMIN ADMIN shell
```

Press Ctrl+D or "exit" to exit

Press "?" or "help" for help

Press TAB for command completion

Press UP and DOWN key for command history

CMM>

The prompt may appear differently depending on the type of firmware as follows:

Prompt in SMCIPMITool shell mode	IPMI Firmware Type
CMM>	Peppercon Firmware (KIRA) for Blade CMM
SIM(W)>	AMI Firmware (WPCM450)
SIM(WA)>	ATEN Firmware (WPCM450)
SIMBL(W)>	AMI Firmware (WPCM450) for Blade SIMBL
SIMBL>	Peppercon Firmware (KIRA) for Blade SIMBL
SIM-IPMI>	Peppercon Firmware (KIRA) without KVM
SIM-KVM-IPMI>	Peppercon Firmware (KIRA) with KVM
SUPERO-IPMI>	OSA (Renesas 2167) Firmware
IPMI>	Others

## 3.15 ver

Entering the ver command will list the version and build of the SMCIPMITool application being used.

Usage: **ver**

Example Output:

```
SMC IPMI Tool V1.7.9(Build 101124) - Super Micro Computer, Inc.
```

## 3.16 ch

Entering the ch command will change the managed device in shell mode.

Usage: **ch <IP> [username] [password]**

## 3.17 list

Entering the list command will display all available commands.

Usage: **list**

## 3.18 find

Entering the find command will search for and display all IPMI devices.

Usage: **find [<Start\_IP> <End\_IP> <NetMask>]**

Example Output:

```
Finding IPMI Devices ...  
  
172.31.100.235      IPMI 2.0 (SuperBlade TwinBlade CMM)  
  
172.31.100.242      IPMI 2.0 (SuperBlade CMM)  
  
2 IPMI device(s) found. Use "found" to list found devices
```

## 3.19 found

Entering the found command will list or clear all found IPMI devices.

Usage: **found [clear]**

## 3.20 exec

Entering the exec command will execute the specified command from a file.

Usage: **exec <filename> <loop> <delay> where**

Loop = 0 is for an infinite loop

Delay is in seconds

## 3.21 host

Entering the host command will list the following host-related subcommands.

### 3.21.1 list

Use the list command will list the host group and host data.

Usage: **host list**

Example Output:

Host :

Host	IP
----	--
1.112	(192.168.1.112)
1.119	(192.168.1.119)
b11	(192.168.10.243)
b12	(192.168.10.244)

Host Group:

Group Name	Host
-----	----
1	1.112
	1.119
b1	b11
	b12

### 3.21.2 reload

Using the reload command will reload the host data.

Usage: **host reload**

### 3.21.3 add

Use the add command to add a host.

Usage: `host add <host> <ip> [username] [password]`

### 3.21.4 remove

Use the remove command to remove a host.

Usage: `host remove <host>`

### 3.21.5 rename

Use the rename command to rename a host.

Usage: `host rename <old name> <new name>`

### 3.21.6 group

Entering the group command will list the following group-related subcommands.

#### 3.21.6.1 add

Use the add command to add a host group.

Usage: `host group add <group> [host] ...`

#### 3.21.6.2 remove

Use the remove command to remove a host group.

Usage: `host group remove <group>`

#### 3.21.6.3 rename

Use the rename command to rename a host group.

Usage: `host group rename <old name> <new name>`

#### 3.21.6.4 addhost

Use the addhost command to add host into an existing host group.

Usage: `host group addhost <group> <host> ...`

#### 3.21.6.5 removehost

Use the removehost command to remove host from an existing host group.

Usage: `host group removehost <group> <host> ...`

## 3.22 hostrun

Enter the hostrun command to run a command on an entire host or group.

Usage: **hostrun** <host|group> <command>

Example:

```
CMM>hostrun bl ipmi power up
```

```
[bl1:192.168.10.243]
```

```
Done
```

```
[bl2:192.168.10.244]
```

```
Done
```

## 3.23 sc

Enter the sc command to execute a DOS or Linux shell command.

Usage: **sc** <command>

Example:

```
CMM>sc dir (execute dir command in Windows OS)
```

```
CMM>sc ls (execute ls command in Linux OS)
```

```
CMM>sc ping 192.168.10.123 (execute ping command)
```

## 3.24 pminfo

Entering the pminfo command will display information on the health of the PMBus.

Usage: **pminfo** [<bus ID> <slave address>]

Example Output:

```
[SlaveAddress = 78h]
```

Item		Value
----		-----
Status		[Status OK]
AC Input Voltage		108.0 V
AC Input Current		1.21 A

DC 12V Output Voltage		12.24 V
DC 12V Output Current		8.87 A
Temperature 1		33C/91F
Temperature 2		36C/97F
Fan 1		9160 RPM
DC 12V Output Power		108 W
AC Input Power		125 W
PMBus Revision		0x0001
PWS Serial Number		P7211C940PT0460
PWS Module Number		PWS-721P-1R
PWS Revision		REV1.0

[SlaveAddress = 7Ah]

Item		Value
----		-----
Status		[Status OK]
AC Input Voltage		108.5 V
AC Input Current		1.35 A
DC 12V Output Voltage		12.08 V
DC 12V Output Current		10.5 A
Temperature 1		35C/95F
Temperature 2		35C/95F
Fan 1		9160 RPM
DC 12V Output Power		126 W
AC Input Power		138 W
PMBus Revision		0x0001
PWS Serial Number		P7211C940PT0459
PWS Module Number		PWS-721P-1R
PWS Revision		REV1.0

## 3.25 nm

Entering the nm command will list the following node management subcommands (applies only to devices that support node management).

### 3.25.1 detect

Use the detect command to detect if ME is present.

Usage: **nm detect**

Example Output:

```
This device supports Node Manager
```

### 3.25.2 ver

Use the ver command to display the node manager version.

Usage: **nm ver**

Example Output:

```
Node Manager Version = 1.5  
Firmware Version     = 1.12
```

### 3.25.3 cap

Use the cap command to display the node manager capabilities.

Usage: **nm cap**

Example Output:

```
Max concurrent settings      = 10  
Max Power limit value        = 32767 w  
Min Power limit value        = 1 w  
Max Correction Time settable = 600000 ms  
Min Correction Time settable = 6000 ms  
Max Statistics Reporting period = 3600 s  
Min Statistics Reporting period = 1 s  
Limiting type                 = CPU power limiting  
Limiting based on             = Wall input power. PSU input power
```

### 3.25.4 status

Use the status command to display or enable or disable the node manager.

Usage: **nm status** [**enable:disable**]

Example Output:

```
Node Manager is enabled
```

### 3.25.5 stat

Use the status command to display power statistics (or by policy ID).

Usage: **nm stat** [**ID**]

Example Output:

```
Global Power statistic
Current = 263 w
Minimum = 0 w
Maximum = 375 w
Average = 259 w
Time    = 12/27/2010 04:50:54
Reporting Period = 1 sec
Node Manager is enabled
Measurements in progress
```

### 3.25.6 resetStat

Use the resetStat command to reset power statistics (or by policy ID).

Usage: **nm resetStat** [**ID**]

### 3.25.7 pstate

Use the pstate command to get or set the P-state.

Usage: **nm pstate** [**value**]

Example Output:

```
Current P-State = 7
Number of P-State = 8
```

### 3.25.8 tstate

Use the tstate command to get or set the T-state.

Usage: **nm tstate [value]**

Example Output:

```
Current T-State = 0
Number of T-State = 8
```

### 3.25.9 ptstate

Use the ptstate command to display the P-state and T-state.

Usage: **nm ptstate**

Example Output:

```
P-State : High | _____#| Low          [7/8] (Current/Number of State)
T-State : High |# _____| Low          [0/8] (Current/Number of State)
```

### 3.25.10 alert

Use the alert command to get or set the destination for alerts. Node Manager will send the alert to the SNMP destination, which can be defined by the “ipmi lan snmp” command.

Usage: **nm alert [destination]**

Example:

```
SIM(WA)>ipmi lan snmp

Seq          IP          MAC
---          --          ---
  1          0.0.0.0    00:00:00:00:00:00
  2    192.168.12.150  00:00:00:00:00:00
  3          0.0.0.0    00:00:00:00:00:00
  4          0.0.0.0    00:00:00:00:00:00
  5          0.0.0.0    00:00:00:00:00:00
  6          0.0.0.0    00:00:00:00:00:00
  7          0.0.0.0    00:00:00:00:00:00
  8          0.0.0.0    00:00:00:00:00:00
```

```

9           0.0.0.0    00:00:00:00:00:00
10          0.0.0.0    00:00:00:00:00:00
11          0.0.0.0    00:00:00:00:00:00
12          0.0.0.0    00:00:00:00:00:00
13          0.0.0.0    00:00:00:00:00:00
14          0.0.0.0    00:00:00:00:00:00
15          0.0.0.0    00:00:00:00:00:00

```

```
SIM(WA)>nm alert 2
```

```
Done
```

```
SIM(WA)>nm alert
```

```
Destination selector = 2
```

### 3.25.11 scanPolicy

Use the scanPolicy command to get or set the destination for alerts.

Usage: **nm scanPolicy [end]**

Example Output:

```
=====
```

```
Policy ID = 0, Power Limit = 32767 w
```

```
Policy state:
```

```
Policy enabled
```

```
Per Domain Node Manager policy control enabled
```

```
Global Node Manager policy control enabled
```

```
Exception action:
```

```
=====
```

```
Policy ID = 2, Power Limit = 200 w
```

```
Policy state:
```

```
Policy enabled
```

```
Per Domain Node Manager policy control enabled
```

```
Global Node Manager policy control enabled
```

```
Exception action:
```

### 3.25.12 addPolicy

Use the addPolicy command to add a new policy.

Usage: nm addPolicy <ID> <limit> <t> <p>

Example:

```
SIM(WA)>nm addPolicy 15 150 60000 10
```

Done

### 3.25.13 delPolicy

Use the delPolicy command to delete a policy.

Usage: nm delPolicy <ID>

### 3.25.14 getPolicy

Use the getPolicy command to get a policy.

Usage: nm getPolicy <ID>

Example:

```
SIM(WA)>nm getPolicy 15
```

```
Power Limit = 150 w
```

```
Correction Time limit      = 60000 ms
```

```
Statistics Reporting Period = 10 s
```

```
Policy state:
```

```
Policy enabled
```

```
Per Domain Node Manager policy control enabled
```

```
Global Node Manager policy control enabled
```

```
Policy Exception action state:
```

```
Send alert
```

### 3.25.15 enablePolicy

Use the enablePolicy command to enable a policy.

Usage: nm disablepolicy <ID>

## 3.25.16 disablePolicy

Use the disablePolicy command to disable a policy.

Usage: `nm disablePolicy <ID>`

## 3.26 deploy

Entering the deploy command will list the following deploy subcommands.

### 3.26.1 one

Use the one command to deploy a BIOS or firmware ISO file for a general server.

Usage: `deploy one <ISO file>`

### 3.26.2 all

Use the all command to deploy a BIOS or firmware ISO file for a SuperBlade system.

Usage: `deploy all <ISO file>`

### 3.26.3 check

Use the check command to check SuperBlade for deploy task.

Usage: `deploy check`

### 3.26.4 status

Use the status command to display the current status of a deployment process.

Usage: `deploy status`

### 3.26.5 clear

Use the clear command to clear and remove all virtual media on a session.

Usage: `deploy clear`

## 3.27 kvmwa

Entering the kvmwa command will open a KVM window for ATEN firmware.

Usage: `kvmwa`

## 3.28 ukvm

Entering the ukvm command will auto-detect the firmware and launch the correct KVM (keyboard/video/mouse) window console.

Usage: **ukvm**

## 3.29 vmwa

Entering the vmwa command will list the following vmwa subcommands (applies only to devices with ATEN firmware). Refer to Appendix B for more on VM commands.

Usage: **vmwa**

Note:

\* Supports 2 virtual devices (device 1 & device 2)

Device 1 will be Hard Disk,USB or Floppy

Device 2 will be CD,DVD or ISO file

\* List available devices before mount virtual media when plug in Removable device

### 3.29.1 dev1list

Use the dev1list command to list the available device for virtual device 1.

Usage: **vmwa dev1list**

### 3.29.2 dev1drv

Use the dev1drv command to mount the drive for virtual device 1.

Usage: **vmwa dev1drv <index>**

### 3.29.3 dev1stop

Use the dev1stop command to stop the virtual device 1.

Usage: **vmwa dev1stop**

### 3.29.4 dev2list

Use the dev2list command to list the available device for virtual device 2.

Usage: **vmwa dev2list**

### 3.29.5 dev2cd

Use the dev2cd command to mount the CD/DVD drive for virtual device 2.

Usage: **vmwa dev2cd <index>**

### 3.29.6 dev2iso

Use the dev2iso command to mount the ISO file for virtual device 2.

Usage: **vmwa dev2iso <filename>**

### 3.29.7 dev2stop

Use the dev2stop command to stop the virtual device 2.

Usage: **vmwa dev2stop**

### 3.29.8 allstatus

Use the allstatus command to show all VMWA status.

Usage: **vmwa allstatus**

### 3.29.9 status

Use the status command to show the status.

Usage: **vmwa status**

Example Output:

```
Device 1: None
```

```
Device 2: None
```

### 3.29.10 log

Use the log command to show the log.

Usage: **vmwa log**

## 3.30 dcmi

Entering the dcmi command will list the following DCMI management subcommands (applies only to devices that support DCMI management).

### 3.30.1 find

Use the find command to search for and display all DCMI devices.

Usage: `dcmi find [<Start_IP> <End_IP> <NetMask>]`

Example Output:

Finding DCMI Devices ...

192.168.12.151 DCMI Ver:0.1

192.168.12.152 DCMI Ver:0.1

2 DCMI device(s) found

## 3.30.2 cap

Use the `cap` command to list the DCMI capabilities information.

Usage: `dcmi cap`

Example Output:

DCMI Version = 0.1

Mandatory Platform capabilities

Temperature Monitor :Compliant

Chassis Power :Compliant

SEL logging :Compliant

Identification Support :Compliant

Optional Platform capabilities

Power Management :Not Compliant

Manageability Access Capabilities

VLAN Capable :Available

SOL Supported :Available

OOB Primary LAN Channel Available :Available

OOB Secondary LAN Channel Available :Not presnt

OOB Serial TMODE Available :Not presnt

In-Band KCS Channel Available :Available

SEL Attributes

SEL automatic rollover enabled :Not presnt  
Number of SEL entries :0

#### Identification Attributes

Asset Tag Support :Available  
DHCP Host Name Support :Not presnt  
GUID Support :Available

#### Temperature Monitoring

Baseboard temperature :At least 1  
Processors temperature :At least 1  
Inlet temperature :At least 1

#### Power Management Device Slave Address

7-bit I2C Slave Address of device on IPMB :10

#### Power Management Controller Channel Number

Channel Number :00  
Device Revision :01

#### Manageability Access Attributes

Mandatory Primary LAN OOB Support (RMCP+ Support Only) :supported  
Optional Secondary LAN OOB Support (RMCP+ Support Only) :supported  
Optional Serial OOB TMODE Capability :supported

## 3.31 dr

Entering the dr command will list the following drive-redirection subcommands (applies only to devices with Peppercon firmware). Refer to Appendix B for more on drive-redirection / VM commands

### 3.31.1 list

Use the list command to list available local drives.

Usage: **dr list**

Example Output:

C: (Hard Disk)

D: (Hard Disk)

E: (CD-ROM)

### 3.31.2 iso

Use the iso command to set the redirection for ISO file.

Usage: **dr iso <drive ID> <path to iso file>**

Example: **dr iso c:\cd.iso**

This will establish an ISO redirection with your cd.iso

Note: If your path includes a space, please place double quote at begin and end of <path to iso file>

### 3.31.3 drv

Use the drv command to set the redirection for local drive.

Usage: **ddr drv <drive ID> <drive Letter> [write ? enable]**

Example 1: **dr drv 1 d**

This will establish a drive redirection with your local d drive.

The write support is disabled

Example 2: **dr drv 1 e enable**

This will establish a drive redirection with your local e drive.

The write support is enabled

## 3.32 kvm

Entering the `kvm` command will open a KVM window for Peppercon firmware.

Usage: `kvm`

## 3.33 kvmw

Entering the `kvmw` command will open a KVM window for AMI firmware.

Usage: `kvmw`

## 3.34 vmw

Entering the `vmw` command will list the following `vmw` subcommands (applies only to devices with AMI firmware). Refer to Appendix B for more on VM commands.

Usage: `vmw`

### 3.34.1 vmw floppy

This command is used to select the floppy image as virtual media.

Usage: `vmw floppy <image file>`

### 3.34.2 vmw usbkey

This command is used to select the USB key as virtual media.

Usage: `vmw usbkey <drive letter>`

### 3.34.3 vmw iso

This command is used to select the ISO file as virtual media.

Usage: `vmw iso <ISO file>`

### 3.34.4 vmw cd

This command is used to select the CD/DVD drive as virtual media.

Usage: `vmw cd <drive letter>`

### 3.34.5 vmw stopFloppy

This command is used to stop the connected floppy.

Usage: `vmw stopFloppy`

### 3.34.6 vmw stopUsbkey

This command is used to stop the connected USB key.

Usage: `vmw stopUsbkey`

### 3.34.7 vmw stopISO

This command is used to stop the connected ISO.

Usage: `vmw stopISO`

### 3.34.8 vmw stopCD

This command is used to stop the connected CD/DVD drive.

Usage: `vmw stopCD`

### 3.34.9 vmw status

This command is used to view the Virtual Media status.

Usage: `vmw status`

## 3.35 sol

Entering the `sol` command will list the following SOL subcommands.

### 3.35.1 sol activate

Use the `sol activate` command to activate SOL directly in the current text mode. Press the <F12> key to exit.

In order to display the remote text console correctly, the support of ANSI/VT100 terminal control escape sequences is required for the computer terminal or terminal emulator running SMCIPMITool.

Usage: `sol activate`

### 3.35.2 sol deactivate

Use the `sol deactivate` command to stop SOL.


Usage: `sol deactivate`

### 3.35.3 sol window

Use the sol window command to open a SOL window GUI and activate SOL.

Usage: `sol window`

Example Output:



### 3.35.4 sol key

Use the sol key command to key map for Linux or Windows.

Usage: `sol key [linux|windows]`

### 3.35.5 bitrate

Use the sol bitrate command to configure the SOL transmission bit rate.

Usage: `sol bitrate [9.6|19.2|38.4|57.6|115.2]`

# Appendix A Command Categories

Refer to the chart below to determine the command sets supported by the stated configurations.

V: Supported

O: Supported and IPMI FW dependent.

Command Set	Blade w/ CMM	Server w/ ATEN IPMI Firmware	Server w/ AMI IPMI Firmware	Server w/ Peppercon IPMI Firmware	Server w/ATEN or AMI IPMI FW, ME enabled BIOS and PMBus power supply
Super Blade Management	O				
IPMI Management	V	V	V	V	V
KVM and Virtual Media for Peppercon, AMI, ATEN		O	O	O	O
Group Management	V	V	V	V	V
Deployment Tool (BIOS Refresh)	O	O	O		O
Shell and Command Mode	V	V	V	V	V
Trap Receiver	V	V	V	V	V
Node Management for ME-enabled MB					V
DCMI Management		V	V		V
PMBus Health					V
IPMI Device Discovery	V	V	V	V	V
Script	V	V	V	V	V

Refer to the chart below for the command set categories of the primary commands.

<b>Category</b>	<b>Commands</b>
<b>Super Blade Management</b>	system, failure, blade, gigabit, power, ib, cmm, listtemp, allsel
<b>IPMI Management</b>	sel, user, ipmi, ver, sol
<b>KVM and Virtual Media for Peppercon, AMI, ATEN</b>	Peppercon: dr, kvm, vm AMI: kvmw, vmw ATEN: kvmwa, vmwa
<b>Group Management</b>	host, hostrun
<b>Deployment Tool (BIOS Refresh)</b>	deploy
<b>Shell and Command Mode</b>	ch
<b>Trap Receiver</b>	trap
<b>Node Management for ME-enabled MB</b>	nm
<b>DCMI Management</b>	dcmi
<b>PMBus Health</b>	pminfo
<b>IPMI Device Discovery</b>	find, found
<b>Script</b>	exec

# Appendix B VM Command Examples

## B.1 AMI IPMI Firmware

Available commands:

<code>vmw floppy &lt;image file&gt;</code>	Floppy image as virtual media
<code>vmw usbkey &lt;drive letter&gt;</code>	USB key as virtual media
<code>vmw iso &lt;ISO file&gt;</code>	ISO file as virtual media
<code>vmw cd &lt;drive letter&gt;</code>	CD/DVD drive as virtual media
<code>vmw stopFloppy</code>	Stop connected floppy
<code>vmw stopUsbkey</code>	Stop connected USBKey
<code>vmw stopISO</code>	Stop connected ISO
<code>vmw stopCD</code>	Stop connected CD/DVD
<code>vmw status(st)</code>	Virtual Media status

Example of using floppy image as virtual media:

```
SIMBL(W)>vmw floppy c:\DOS50.img
```

```
Connecting ...Done
```

```
SIMBL(W)>vmw stopFloppy
```

```
Disconnecting ...Done
```

Example of using USB key as virtual media:

```
SIMBL(W)>vmw usbkey h
```

```
Connecting ...Done
```

```
SIMBL(W)>vmw stopUsbkey
```

```
Disconnecting ...Done
```

Example of using ISO file as virtual media:

```
SIMBL(W)>vmw iso c:\fdoem.iso
```

```
Connecting ...Done
```

```
SIMBL(W)>vmw stopISO
```

```
Disconnecting ...Done
```

Example of using CD/DVD drive as virtual media:

```
SIMBL(W)>vmw cd e
```

```
Connecting ...Done
```

```
SIMBL(W)>vmw stopCD
```

```
Disconnecting ...Done
```

Example of displaying Virtual Media status:

```
SIMBL(W)>vmw status
```

```
IP : 192.168.12.163
```

```
Target Drive : Virtual Floppy
```

```
Read Bytes : n/a
```

```
Status : Not Connected
```

```
Connected to :
```

```
Target Drive : Virtual CD
```

```
Read Bytes : n/a
```

```
Status : Not Connected
```

```
Connected to :
```

## B.2 ATEN IPMI Firmware

Available commands:

```
vmwa devl1ist List available devices for virtual device 1
```

```
vmwa devl1drv <index> Mount drive for virtual device 1
```

```
vmwa devl1stop Stop virtual device 1
```

vmwa dev2list	List available devices for virtual device 2
vmwa dev2cd <index>	Mount CD/DVD for virtual device 2
vmwa dev2iso <filename>	Mount ISO file for virtual device 2
vmwa dev2stop	Stop virtual device 2
vmwa allstatus	Show all VMWA status
vmwa status	Show status
vmwa log	Show log

#### Notes:

\* Supports 2 virtual devices (device 1 & device 2 )

Device 1 will be Hard Disk,USB or Floppy

Device 2 will be CD,DVD or ISO file

\* List available devices before mounting virtual media when plugged in Removable device

Example of using USB key as virtual media:

**SIM(WA)>vmwa dev1list**

2: [H: USB Flash]

3: [G: USB HD]

4: [I: USB HD]

5: [C: IDE HD]

6: [D: IDE HD]

**SIM(WA)>vmwa dev1drv 2**

Mounting H: USB Flash

Device 1 :VM Plug-In OK!!

**SIM(WA)>vmwa dev1stop**

done

Example of using CDROM as virtual media:

```
SIM(WA)>vmwa dev2list
```

```
2: [E: IDE CDROM]
```

```
3: [F: SCSI CDROM]
```

```
SIM(WA)>vmwa dev2cd 2
```

```
Mounting E: IDE CDROM
```

```
Device 2 :VM Plug-In OK!!
```

```
SIM(WA)>vmwa dev2stop
```

```
Done
```

Example of using ISO image file as virtual media:

```
SIM(WA)>vmwa dev2iso c:\fdoem.iso
```

```
Mounting ISO file: c:\fdoem.iso
```

```
Device 2 :VM Plug-In OK!!
```

```
SIM(WA)>vmwa dev2stop
```

```
Done
```

Example of showing all VMWA status, status and log:

```
SIM(WA)>vmwa allstatus
```

```
[192.168.12.151]:
```

```
Device 1: H: USB Flash
```

```
Device 2: None
```

```
SIM(WA)>vmwa status
```

```
Device 1: None
```

```
Device 2: ISO File [c:\fdoem.iso]
```

```
SIM(WA)>vmwa log
```

```
Device 1 :Don't access file on Local storage device
```

```
Device 1 :VM Plug-In OK!!
```

Device 1 :VM Plug-Out OK!! Stop!!

Device 2 :VM Plug-In OK!!

Device 2 :VM Plug-Out OK!! Stop!!

Device 2 :VM Plug-In OK!!

## B.3 Peppercon IPMI Firmware

Available commands for ISO / Drive Redirection:

```
dr list                               List available local drive
dr iso <drive ID> <path to iso file>  Set ISO redirection
dr drv <drive ID> <drive Letter> [write ? enable]  Set drive redirection
```

Example of using ISO image redirection:

```
SIMBL>dr iso 1 c:\fdoem.iso
```

```
Connecting Drive Redirection to 192.168.12.123
```

```
MSP: trying connection to 192.168.12.123:443
```

```
MSP: connected successfully to 192.168.12.123:443
```

```
Done
```

Note: ISO redirection will stop once you quit the shell mode

Example of using Drive redirection:

```
SIMBL>dr list
```

```
A: (Removable)
```

```
C: (Hard Disk)
```

```
D: (Hard Disk)
```

```
E: (CD-ROM)
```

```
F: (CD-ROM)
```

```
G: (Hard Disk)
```

```
I: (Hard Disk)
```

**SIMBL>dr drv 1 G**

Connecting Drive Redirection to 192.168.12.123

MSP: trying connection to 192.168.12.123:443

MSP: connected successfully to 192.168.12.123:443

Done

**Note:** The drive redirection will stop once you quit shell mode

**Available commands for Virtual Media:**

vm status(st)	Virtual media status
vm stop	Stop virtual media
vm floppy	Upload a floppy image as virtual media
vm iso	Virtual media via windows share

**Example of using floppy image and ISO image as virtual media:**

**SIMBL>vm floppy 1 c:\dos50.img**

Uploading floppy

.....  
.....

Done

**SIMBL>vm iso 2 192.168.12.158 blade /ISO/XPE.iso**

Done

**SIMBL>vm status**

Drive 1

Device Status = Internal image set

Image Size = 1474560 (bytes)

Access Mode = Writable

Image source = dos50.img

Drive 2

Device Status = CD-ROM image on Windows share set

Image Size = 89565184 (bytes)

Access Mode = Read-Only

Image source = //192.168.12.158/blade//ISO/XPE.iso

# Appendix C Trap Receiver

## Available commands:

trap start	Start Trap receiver
trap stop	Stop Trap receiver
trap status(st)	Trap receiver status
trap list	List the received Traps
trap clear	Clear the received Traps
trap save	Save the received Traps to file
trap savepet	Save as the IPMIView TrapReceiver PET format

## Example of using Trap Receiver:

```
SIM(WA)>ipmi lan snmp
```

Seq	IP	MAC
---	--	---
1	192.168.12.174	00:00:00:00:00:00
2	0.0.0.0	00:00:00:00:00:00
3	0.0.0.0	00:00:00:00:00:00
4	0.0.0.0	00:00:00:00:00:00
5	0.0.0.0	00:00:00:00:00:00
6	0.0.0.0	00:00:00:00:00:00
7	0.0.0.0	00:00:00:00:00:00
8	0.0.0.0	00:00:00:00:00:00
9	0.0.0.0	00:00:00:00:00:00
10	0.0.0.0	00:00:00:00:00:00
11	0.0.0.0	00:00:00:00:00:00
12	0.0.0.0	00:00:00:00:00:00
13	0.0.0.0	00:00:00:00:00:00
14	0.0.0.0	00:00:00:00:00:00

15                    0.0.0.0      00:00:00:00:00:00

**SIM(WA)>trap status**

Trap Receiver status: Stopped

Trap Received        : 0

**SIM(WA)>trap start**

Trap Receiver Started

(Trap receiver is started by default. See SMCIPMITool.properties)

(When the trap receiver got a SNMP trap, a notice will be displayed.)

**SIM(WA) [!Trap(1)]>Info: Use "trap" command for detail.**

**SIM(WA) [!Trap(1)]>trap list**

-----  
Trap (1)

Sender            = 192.168.12.151

Community        = public

Sensor            = FAN 3

Local Time Stamp = 2011/01/03 00:25:32 Mon

Description :

Event Dir : De-assertion

Lower Non-recoverable - going low  
-----

**SIM(WA) [!Trap(1)]>trap save snmp.txt**

"snmp.txt" file saved

**SIM(WA) [!Trap(1)]>trap savepet snmp.pet**

"snmp.pet" file saved

**SIM(WA) [!Trap(1)]>trap clear**

Trap cleared

**SIM(WA)>trap stop**

Trap Receiver stopped

**SIM(WA)>trap status**

Trap Receiver status: Stopped

Trap Received : 0